



BSA SERVICE SHEET No. 808B

"D" GROUP MODELS WIRING DIAGRAMS


Lucas D.C. Lighting




LIGHTING OFF
(TURN LT SW TO 'O')
EMERGENCY IGNITION ON
(TURN IGNITION KEY LEFT)



LIGHTING OFF
(TURN LT SW LEFT TO 'O')
IGNITION OFF
(TURN IGNITION KEY CENTRAL)




TAIL & PILOT LTS ON
(TURN LT SW RIGHT TO 'T')
IGNITION ON
(TURN IGNITION KEY RIGHT)





TAIL & HEAD LTS ON
(TURN LT SW RIGHT TO 'M')

DIAGRAMS SHOWING SWITCH POSITIONS LOOKING ON TOP OF SWITCH



Wipac A.C. Lighting




ABOVE: Wiring diagram for Wipac A.C. lighting when fitted with remotely controlled switch operated by handlebar lever.

LEFT: Wiring diagram for Wipac A.C. lighting system when switch is mounted on top of the headlamp shell.

B.S.A. Service Sheet No. 808B (contd.)

Wipac A.C. Lighting
(Negative Earth System)



B.S.A. Service Sheet No. 808B (contd.)

Wipac A.C. Lighting
(Positive Earth System)

